

6

5

4

3

2

1

C6150/C6050/C5950/C5850/C5750/C5650  
C6100/C5900/C5800/C5700/C5600/C5500  
C5550MFP  
Second Tray Unit  
RSPL

Related drawings

Drawing No.	Name
43347601TL	Unit 2nd Tray(PX734 ODA) Disassembly Drawing
43347601TH	Unit 2nd Tray(PX734 ODA) Maintenance Manual

Bom		Use for		Certification Body	
Rev	Date	DCO No.	Contents	Design	Approval
2	2006-03-13	SE7-0739	Add G mark	Yujiro Iida	Yujiro Iida
3	2006-12-04	SA9-1667	Drawing Maintenance	Hiroimi Kano	Koji Aida
4	2007-02-09	SP7-3490	Add C5550MFP(Page 3)	Masato Yamazaki	Hideki Enomoto
5	2008-04-01	SAB-0090	Add product name	Koji Aida	Koji Aida
Approval		Yujiro Iida		Design S Ogashiwa	
Check				Name	
				Unit 2nd Tray(PX734 ODA)	
				Recom. spare part. lst	
Date		2005-11-14		Drawing No.	
		Okidata Corporation		43347601TR	
				1/	

**Applicable**

Part No.	Printer Series	Destination	Voltage	Model No.	Note
43347601	PX734/5, PX744/5	ODA		N31181A	
43347602	PX734/5, PX744/5	OEL		N31181A	
43347603	PX734/5, PX744/5	AOS		N31181A	
43347604	PX734/5	JPN		N31181A	
43347606	PX735	AOS-ES		N31181A	
43347607	PX735	FUJITSU		N31181A	
43347608	PX735MFP	ODA		N31183A	
43347609	PX735MFP	OEL		N31183A	
43347610	PX735MFP	AOS		N31183A	
43347611	PX735MFP	AOS-ES		N31183A	

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	Second Tray Unit	1	43336402	2nd Tray-Unit PX734	1	1	2	4				-
	Second Tray Unit	2	42139803	Case-CASS-Assy	1	1	2	4				G
	Second Tray Unit	3	42136603	Guide Assy.-CassetteL	1	1	2	4				G
	Second Tray Unit	4	42136803	Guide Assy.-CassetteR	1	1	2	4				G
	Second Tray Unit	5	43336601	Frame-Assy-Hopping PX734	1	2	4	8				-
	Second Tray Unit	6	42052601	Roller Assy.-Hopping	1	2	4	8				G
	Second Tray Unit	7	40313201	Roller Assy.-Feed	1	1	2	4				G
	Second Tray Unit	8	41400001	Shaft-Roller	1	1	2	4				G
	Second Tray Unit	9	42138602	Cover Assy.-Front	1	2	4	8				G
	Second Tray Unit	10	41438401	Frame Assy.-Separation	1	2	4	8				G
	Second Tray Unit	11	41439401	Spring-Separation	2	2	4	8				G
	Second Tray Unit	12	42629401	Motor-Pulse-Fuser	1	2	4	8				G
	Second Tray Unit	13	42197702	OR-Clutch(24V)	1	2	4	8				G
	Second Tray Unit	14	43133101	OR-V7Y	1	3	6	12	Board			-
	Second Tray Unit	15	40135301	Photo-Interrupter	3	2	4	8				G
	Second Tray Unit	16	2233014P0100	9715S-10Z02-G4C	1	1	2	4				G
	Second Tray Unit	17	43306801	CONN Cord-AMP10P-AMP13P	1	1	2	4	V7Y-Plug			G
	Second Tray Unit	18	43326901	CONN Cord-AMP3P-AMP3P	1	1	2	4	V7Y-P-End			G
	Second Tray Unit	19	43155801	CONN Cord-AMP4P-AMP4P	1	1	2	4	V7Y-Motor			G
	Second Tray Unit	20	42142802	CONN Cord-JST6P-AMP3PX2	1	1	2	4	V7Y-Paper Loading and 1st-Tray SNS			G
	Second Tray Unit	21	42145402	Cover-2nd Tray	1	1	2	4				-
	Second Tray Unit	22	1051010C0001	TC-16-10-10	1	1	2	4				G
	Second Tray Unit	23	42677901	Cover-FH-R	1	1	2	4				-
	Second Tray Unit	24	42678001	Cover-FH-L	1	1	2	4				-
	Second Tray Unit	25	42932708	TappingScrew-B2 L=8	16	-	-	-				-
	Second Tray Unit	26	42920406	Cup_Screw (S Tight M3)	6	-	-	-				-
	Second Tray Unit	27	42920408	Cup_Screw A	1	-	-	-				-
	Second Tray Unit	28	RE3-SK	Ring	1	-	-	-			D	-
	Second Tray Unit	28	42890501	Screw-Shoulder	2	-	-	-				-
	Second Tray Unit	29	RE4-SK	Ring	1	-	-	-				-
	Second Tray Unit C5550MFP	1	43336403	2nd Tray-Unit PX735MFP	1	1	2	4				-
	Second Tray Unit C5550MFP	2	42139803	Case-CASS-Assy	1	1	2	4				G
	Second Tray Unit C5550MFP	3	42136603	Guide Assy.-CassetteL	1	1	2	4				G
	Second Tray Unit C5550MFP	4	42136804	Guide Assy.-CassetteR-MFP	1	1	2	4				G
	Second Tray Unit C5550MFP	5	43336601	Frame-Assy-Hopping PX734	1	2	4	8				-
	Second Tray Unit C5550MFP	6	42052601	Roller Assy.-Hopping	1	2	4	8				G
	Second Tray Unit C5550MFP	7	40313201	Roller Assy.-Feed	1	1	2	4				G
	Second Tray Unit C5550MFP	8	41400001	Shaft-Roller	1	1	2	4				G
	Second Tray Unit C5550MFP	9	42138602	Cover Assy.-Front	1	2	4	8				G
	Second Tray Unit C5550MFP	10	41438401	Frame Assy.-Separation	1	2	4	8				G
	Second Tray Unit C5550MFP	11	41439401	Spring-Separation	2	2	4	8				G
	Second Tray Unit C5550MFP	12	42629401	Motor-Pulse-Fuser	1	2	4	8				G

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	Second Tray Unit C5550MFP	13	42197702	OR-Clutch(24V)	1	2	4	8				G
	Second Tray Unit C5550MFP	14	43133101	OR-V7Y	1	3	6	12	Board			-
	Second Tray Unit C5550MFP	15	40135301	Photo-Interrupter	3	2	4	8				G
	Second Tray Unit C5550MFP	16	2233014P0100	9715S-10Z02-G4C	1	1	2	4				G
	Second Tray Unit C5550MFP	17	43306801	CONN Cord-AMP10P-AMP13P	1	1	2	4	V7Y-Plug			G
	Second Tray Unit C5550MFP	18	43326901	CONN Cord-AMP3P-AMP3P	1	1	2	4	V7Y-P-End			G
	Second Tray Unit C5550MFP	19	43155801	CONN Cord-AMP4P-AMP4P	1	1	2	4	V7Y-Motor			G
	Second Tray Unit C5550MFP	20	42142802	CONN Cord-JST6P-AMP3PX2	1	1	2	4	V7Y-Paper Loading and 1st-Tray SNS			G
	Second Tray Unit C5550MFP	21	42145402	Cover-2nd Tray	1	1	2	4				-
	Second Tray Unit C5550MFP	22	1051010C0001	TC-16-10-10	1	1	2	4				G
	Second Tray Unit C5550MFP	23	42677901	Cover-FH-R	1	1	2	4				-
	Second Tray Unit C5550MFP	24	42678001	Cover-FH-L	1	1	2	4				-
	Second Tray Unit C5550MFP	25	42932708	TappingScrew-B2 L=8	16	-	-	-				-
	Second Tray Unit C5550MFP	26	42920406	Cup_Screw (S Tight M3)	6	-	-	-				-
	Second Tray Unit C5550MFP	27	42920408	Cup_Screw A	1	-	-	-				-
	Second Tray Unit C5550MFP	28	42890501	Screw-Shoulder	2	-	-	-				-
	Second Tray Unit C5550MFP	29	RE4-SK	Ring	1	-	-	-				-
	Second Tray Unit C5550MFP	30	43649101	Piece-2nd-Tray	1	1	2	4				-